"Explanation of an Resistive Load"

<u>Resistive Load:</u> is a load in an electrical circuit where there is no reactance, inductance, or capacitance.

Current (amps) is steady from the initial inrush until the interruption of the electrical power.

Resistive loads are typically used to create heat and incandescent lighting.

DesignStein LLC ***Product Engineering***
2402 College Hills Blvd #4, San Angelo, TX 76904
P: 325-227-6053 F: 325-617-7908
designsteinllc@gmail.com